Plaza Hocksett Toll (Main)

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI INITIALS	COMMENTS
LANE LEVEL				
Receipt Printer	Inspect and check signal cable	1 Week	(D) (D) (D)	
Touch Screen	Inspect and check cable connections	1 Week	(D) (D) (D)	
Booth Speaker	Inspect and check cable connections	1 Week	(a) (b) (c) (d)	
VES Camera	Inspect, check cable connections and alignment	1 Week	G 83 83 63	
VES Lights	Inspect and check power cable	1 Week	(C) (C) (C)	
Triple Vault Cabinet	Inspect and adjust diverter cams	1 Week		e.
Double Vault Cabinet	Inspect and adjust diverter cams	1 Week		
ACM Monitor and Mouse	Inspect and check cable connections	1 Week		
Canopy Override Switch	Inspect / Test	1 Week	(5) (5) (5)	
Attendant Identification Display	Inspect and check cable connections	1 Week	(2) (2) (2)	
Treadle Pad	Inspect and check cable connections	1 Week	(D) (D) (D)	
Traffic Loop	Inspect and check for functionality	1 Week	(D) (D) (D) (D)	
Portable Terminal (PDA)	Inspect and check for connectivity	2 Week		
Coin Sorter	Inspect, clean and calibrate	2 Week		
Lane Controller	Inspect and clean	1 Month	(D)	
Patron Fare Display	Clean Front Window	1 Month	CD	
Island Traffic Signals	Clean Front Lens	1 Month	(A)	
Autosense II	Sensor Beam Measurements	3 Months	1	
AVI (MARKIV) Antenna	Inspect, clean and check cable	3 Months	_	
AVI (MARKIV) RF Module	Inspect	3 Months		
Autosense II	Inspect, clean lens and check cable connections	3 Months		

		6 Months	inspect, clean	Host Computer Subsystems
	*	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToil)
	1	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
				HOST LEVEL
	B		Check Battery Condition	UPS Units
	(None	Ethernet Communications Hub
	١	6 Months	Inspect and check cable connections	VES Server
- Address of the Control of the Cont)	6 Months	Inspect and check cable connections	Laser Printer
)	6 Months	inspect and check cable connections	Plaza Workstation
		1 Month	Inspect and check cable connections	Wireless Access Point
- Address - Addr		1 Month	Inspect and check cable connections	Leased Modems
		3 Months	Inspect and clean	AVI (MARKIV) Cabinet
The second secon				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

Hooket Side Read

Attendant Identification Display AVI (MARKIV) RF Module ACM Monitor and Mouse Portable Terminal (PDA) Canopy Override Switch AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Triple Vault Cabinet Patron Fare Display LANE LEVEL Receipt Printer COMPONENT Booth Speaker Lane Controller Touch Screen VES Camera Autosense II Autosense II Treadle Pad Coin Sorter Traffic Loop VES Lights inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for functionality Inspect and check for connectivity Inspect and adjust diverter cams Inspect and adjust diverter cams inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Clean Front Lens inspect and clear Inspect / Test Inspect INTERVAL 3 Months 3 Months 3 Months 3 Months 1 Month 1 Week 2 Week 2 Week 1 Week 1 Week 1 Week 1 Week 1 Month 1 Month ට 9 B G ਰ 8 TRMI INITIALS G 0 3 J J 3 3 J J J 3 S Î 0 Ø G Э 0 0 0 0 COMMENTS

. V . 177 a.

Month Pater Feb 2011

		6 Months	Inspect, clean	Host Computer Subsystems
	Ja.	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToll)
was de principal de la constant de l	M	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
				HOST LEVEL
	(S)		Check Battery Condition	UPS Units
	\		None	Ethernet Communications Hub
- And Andrews		6 Months	Inspect and check cable connections	VES Server
		6 Months	Inspect and check cable connections	Laser Printer
		6 Months	Inspect and check cable connections	Plaza Workstation
		1 Month	Inspect and check cable connections	Wireless Access Point
A A A A A A A A A A A A A A A A A A A	The state of the s	1 Month	Inspect and check cable connections	Leased Modems
		3 Months	Inspect and clean	AVI (MARKIV) Cabinet
				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

Plaza Bed bod Tell

		{	/		3 Months	Inspect, clean lens and check cable connections	Autosense II
TO ANALYSIS AND AN		1	ĺ		3 Months	Inspect	AVI (MARKIV) RF Module
		1	(3 Months	Inspect, clean and check cable	AVI (MARKIV) Antenna
		ļ			3 Months	Sensor Beam Measurements	Autosense II
		~	Q)		1 Month	Clean Front Lens	Island Traffic Signals
		~	F		1 Month	Clean Front Window	Patron Fare Display
Installed all New Lone Controllers,		V	(D)		1 Month	Inspect and clean	Lane Controller
					2 Week	inspect, clean and calibrate	Coin Sorter
			}	{	2 Week	Inspect and check for connectivity	Portable Terminal (PDA)
	◇	3	ð	9	1 Week	Inspect and check for functionality	Traffic Loop
Repland Transk in 35.	⊘	(D)	Ø	Œ	1 Week	Inspect and check cable connections	Treadle Pad
	Ø		ð	B	1 Week	Inspect and check cable connections	Attendant Identification Display
	9	B	Ġ	(3)	1 Week	Inspect / Test	Canopy Override Switch
				\	1 Week	Inspect and check cable connections	ACM Monitor and Mouse
				(1 Week	Inspect and adjust diverter cams	Double Vault Cabinet
	-			ĵ	1 Week	Inspect and adjust diverter cams	Triple Vault Cabinet
	Ì	Ø	ð	9	1 Week	Inspect and check power cable	VES Lights
	Ø	(Z)	T	Θ	1 Week	Inspect, check cable connections and alignment	VES Camera
	S	CD	8	Ø	1 Week	Inspect and check cable connections	Booth Speaker
	0	CD	\mathbb{C}	ଚ	1 Week	Inspect and check cable connections	Touch Screen
	9	C)	ଚ	ଟ	1 Week	Inspect and check signal cable	Receipt Printer
							LANE LEVEL
COMMENTS	S	TRMI INITIALS	TRMI -		INTERVAL	MAINTENANCE TASK	COMPONENT

Month to Feb 2011

3
M
(T)
)
!
)
)
T
TRMI Intials

		3 Months	Inspect, clean lens and check cable connections	Autosense II
		3 Months	Inspect	AVI (MARKIV) RF Module
		3 Months	Inspect, clean and check cable	AVI (MARKIV) Antenna
		3 Months	Sensor Beam Measurements	Autosense li
	22	1 Month	Clean Front Lens	Island Traffic Signals
	-77	1 Month	Clean Front Window	Patron Fare Display
	77	1 Month	Inspect and clean	Lane Controller
	33 37	2 Week	Inspect, clean and calibrate	Coin Sorter
	37 37	2 Week	Inspect and check for connectivity	Portable Terminal (PDA)
	27 27 77 77	1 Week	Inspect and check for functionality	Traffic Loop
Replaced NI	77 77 72 77	1 Week	Inspect and check cable connections	Treadle Pad
	77 77 77 77	1 Week	Inspect and check cable connections	Attendant Identification Display
	77 77 77 77	1 Week	Inspect / Test	Canopy Override Switch
	77 77 77 77	1 Week	Inspect and check cable connections	ACM Monitor and Mouse
		1 Week	Inspect and adjust diverter cams	Double Vault Cabinet
	77 77 77 77	1 Week	Inspect and adjust diverter cams	Triple Vault Cabinet
	77 77 77 71	1 Week	Inspect and check power cable	VES Lights
	77 77 77 71	1 Week	Inspect, check cable connections and alignment	VES Camera
	77 21 77 77	1 Week	Inspect and check cable connections	Booth Speaker
i dell'altra di la contra di la	77 77 77 77	1 Week	Inspect and check cable connections	Touch Screen
	77 77 27 77	1 Week	Inspect and check signal cable	Receipt Printer
				LANE LEVEL
COMMENTS	TRMI INITIALS	INTERVAL	MAINTENANCE TASK	COMPONENT

Month Ex. + 10 2/11

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months		
Leased Modems	Inspect and check cable connections	1 Month	77	Table and the state of the stat
Wireless Access Point	Inspect and check cable connections	1 Month	77	
Plaza Workstation	Inspect and check cable connections	6 Months		- Address - Addr
Laser Printer	Inspect and check cable connections	6 Months		
VES Server	Inspect and check cable connections	6 Months		TATALAN TA
Ethernet Communications Hub	None)	
UPS Units	Check Battery Condition		7)	
HOST LEVEL	Check database status and performance Receive	1 Week	1	
Host Computer Database (TRToll)	Check database status and performance Receive database export, test backups	1 Week	-UR	
Host Computer Subsystems	Inspect, clean	6 Months		

Plaza Exit 11

		3 Months	Inspect, clean lens and check cable connections	Autosense II
	***************************************	3 Months	Inspect	AVI (MARKIV) RF Module
		3 Months	Inspect, clean and check cable	AVI (MARKIV) Antenna
		3 Months	Sensor Beam Measurements	Autosense II
	77	1 Month	Clean Front Lens	Island Traffic Signals
	77	1 Month	Clean Front Window	Patron Fare Display
	77	1 Month	Inspect and clean	Lane Controller
	71 71	2 Week	Inspect, clean and calibrate	Coin Sorter
	22 27	2 Week	Inspect and check for connectivity	Portable Terminal (PDA)
	77 77 77 77	1 Week	Inspect and check for functionality	Traffic Loop
	D W 60 66	1 Week	Inspect and check cable connections	Treadle Pad
	30 73 77 78	1 Week	Inspect and check cable connections	Attendant Identification Display
	77 77 77 77	1 Week	Inspect / Test	Canopy Override Switch
	77 77 77 73	1 Week	Inspect and check cable connections	ACM Monitor and Mouse
		1 Week	Inspect and adjust diverter cams	Double Vault Cabinet
	77 77 77 77	1 Week	Inspect and adjust diverter cams	Triple Vault Cabinet
	77 77 77 77	1 Week	inspect and check power cable	VES Lights
	77 77 71 77	1 Week	Inspect, check cable connections and alignment	VES Camera
	77 27 27 27	1 Week	Inspect and check cable connections	Booth Speaker
	22 22 22 22	1 Week	Inspect and check cable connections	Touch Screen
	77 77 77 77	1 Week	Inspect and check signal cable	Receipt Printer
				LANE LEVEL
COMMENTS	TRMI INITIALS	INTERVAL	MAINTENANCE TASK	COMPONENT

Month Exit 11 2/11

	77		Check Battery Condition	UPS Units
			None	Ethernet Communications Hub
AND THE REAL PROPERTY OF THE P		6 Months	Inspect and check cable connections	VES Server
		6 Months	Inspect and check cable connections	Laser Printer
- AMANGATATING A		6 Months	Inspect and check cable connections	Plaza Workstation
	77	1 Month	Inspect and check cable connections	Wireless Access Point
- Consideration of the Constant of the Constan	77	1 Month	inspect and check cable connections	Leased Modems
		3 Months	Inspect and clean	AVI (MARKIV) Cabinet
				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

Host Computer Subsystems	Check data Host Computer Database (TRToll)	Check data Host Computer Database (Toll)	HOST LEVEL
Inspect, clean	Check database status and performance Receive database export, test backups	Check database status and performance Receive database export, test backups	
6 Months	1 Week	1 Week	
	H	Jr.	

Plaza Exit 12

IZA Exit 17				Month Feb 11
COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI INITIALS	COMMENTS
LANE LEVEL				
Receipt Printer	inspect and check signal cable	1 Week	1 Week 97 77 77 77	
Touch Screen	Inspect and check cable connections	1 Week	22 23 21 21	

				- Control (All Control
COMPONENT	MAINTENANCE TASK	INTERVAL	TRMIINITIALS	COMMENTS
LANE LEVEL				
Receipt Printer	inspect and check signal cable	1 Week	77 77 77 77	
Touch Screen	Inspect and check cable connections	1 Week	77 71 71 71	
Booth Speaker	Inspect and check cable connections	1 Week	77 77 77 77	
VES Camera	Inspect, check cable connections and alignment	1 Week	77 77 77 77	
VES Lights	Inspect and check power cable	1 Week	16 66 EE 66	
Triple Vault Cabinet	Inspect and adjust diverter cams	1 Week	77 77 77 77	
Double Vault Cabinet	Inspect and adjust diverter cams	1 Week		
ACM Monitor and Mouse	Inspect and check cable connections	1 Week	77 77 77 77	
Canopy Override Switch	inspect / Test	1 Week	77 27 27 27	
Attendant Identification Display	Inspect and check cable connections	1 Week	27 27 77 27	
Treadle Pad	Inspect and check cable connections	1 Week	77 77 77 77	Replaced NI
Traffic Loop	Inspect and check for functionality	1 Week	77 77 77 77	
Portable Terminal (PDA)	Inspect and check for connectivity	2 Week	77 77	
Coin Sorter	Inspect, clean and calibrate	2 Week	77 77	
Lane Controller	Inspect and clean	1 Month	77	
Patron Fare Display	Clean Front Window	1 Month	77	
Island Traffic Signals	Clean Front Lens	1 Month	77	
Autosense II	Sensor Beam Measurements	3 Months		
AVI (MARKIV) Antenna	Inspect, clean and check cable	3 Months		
AVI (MARKIV) RF Module	Inspect	3 Months		
Autosense II	Inspect, clean lens and check cable connections	3 Months		

Month Exit 12 2/11

Administra	77		Check Battery Condition	UPS Units
)		None	Ethernet Communications Hub
- Annual - A		6 Months	Inspect and check cable connections	VES Server
To Address of the Control of the Con		6 Months	Inspect and check cable connections	Laser Printer
	`	6 Months	Inspect and check cable connections	Plaza Workstation
	22	1 Month	Inspect and check cable connections	Wireless Access Point
TANANAN TANANA	77	1 Month	Inspect and check cable connections	Leased Modems
		3 Months	Inspect and clean	AVI (MARKIV) Cabinet
				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

	6 Months	Inspect, clean	Host Computer Subsystems
The state of the s	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToll)
**	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
			HOST LEVEL

Month February 2011

Plaza Hampton Main

Attendant Identification Display AVI (MARKIV) RF Module Portable Terminal (PDA) Canopy Override Switch ACM Monitor and Mouse AVI (MARKIV) Antenna Island Traffic Signals Double Vault Cabinet Patron Fare Display Triple Vault Cabinet Lane Controller LANE LEVEL Booth Speaker COMPONENT Receipt Printer Autosense II Autosense II Touch Screen VES Camera Traffic Loop Treadle Pad Coin Sorter VES Lights Inspect, clean lens and check cable connections inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for connectivity Inspect and check for functionality Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Clean Front Lens Inspect and clean Inspect / Test Inspect INTERVAL 3 Months 3 Months 3 Months 3 Months 1 Month 1 Month 1 Month 1 Week ΝÄ Z. Z/A Z/A Z Z/A 3/5 ζ. 11/1 7 NA N A Z A Z X ΝŅ N N Š ૈ TRMI INITIALS ₹ `` N. 10 N/A 1 Ν× N/A N. 3 N/A 7 W N/A Z N/A N/A · · · N/A N/A ۳. 700 S N/A N/A 1 ٦. ا io. , n N. N/A N/A ion. Č Replaced cables in N2 and S4 Replaced treadle in S4 COMMENTS

Month February 2011

COMBONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months	C v 2	
Leased Modems	inspect and check cable connections	1 Month	\ \ \	
Wireless Access Point	Inspect and check cable connections	N/A	N/A	
Plaza Workstation	inspect and check cable connections	6 Months	محد و رية	
Laser Printer	Inspect and check cable connections	6 Months	7	
VES Server	Inspect and check cable connections	6 Months	27)	
Ethernet Communications Hub	None		\	
UPS Units	Check Battery Condition		W	
			•	
HOST LEVEL				
Host Computer Database (Toll)	Check database status and performance Receive database export, test backups	1 Week	李	
Host Computer Database (TRToll)	Check database status and performance Receive database export, test backups	1 Week	3	
Host Computer Subsystems	Inspect, dean	6 Months		

Plaza Hampton Side Road

Attendant Identification Display AVI (MARKIV) RF Module ACM Monitor and Mouse Portable Terminal (PDA) Canopy Override Switch AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Triple Vault Cabinet Patron Fare Display LANE LEVEL COMPONENT Lane Controller Booth Speaker Receipt Printer Touch Screen Autosense II Autosense II VES Camera Treadle Pad Coin Sorter Traffic Loop VES Lights Inspect, check cable connections and alignment Inspect, clean lens and check cable connections Inspect and check for functionality Inspect and check for connectivity Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect and check power cable Inspect, clean and check cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Clean Front Lens Inspect and clean Inspect / Test Inspect 3 Months INTERVAL 3 Months 3 Months 3 Months 1 Month 1 Month 1 Week 1 Month Z A Z ΖX N/A N/A × É 3 ξ ΝÃ N/A Z X Z. ر د NA 3 Š TRMI INITIALS ر کر 3 Z Z \$. . . N/A Ķ ¥ 7. ž 1 1 Z Z/A 7 12 5/2 3 N/A N/A A. ... \$ N/A ي ت N/A <u>~</u> N/A W. N/ ξ, ્રે N/A **1**5 N/A . E N/A Z/A 1 COMMENTS

Month February 2011

Month February 2011

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL			A de la constantina della cons	
AVI (MARKIV) Cabinet	Inspect and clean	3 Months	* 1 ×	
Leased Modems	Inspect and check cable connections	1 Month	<32	
Wireless Access Point	Inspect and check cable connections	N/A	N/A	,
Plaza Workstation	Inspect and check cable connections	6 Months	SA	
Laser Printer	Inspect and check cable connections	6 Months	500	
VES Server	Inspect and check cable connections	6 Months	E 12 W.	
Ethernet Communications Hub	None		<i>'</i>	
UPS Units	Check Battery Condition		W	
HOST LEVEL				
Host Computer Database (Toll)	Check database status and performance Receive database export, test backups	1 Week	W	
Host Computer Database (TRToil)	Check database status and performance Receive database export, test backups	1 Week	₩	
Host Computer Subsystems	Inspect, clean	6 Months	\	

Host Computer Subsystems

6 Months

Month February 2011

Plaza Dover Toll Plaza

Attendant Identification Display AVI (MARKIV) RF Module ACM Monitor and Mouse Portable Terminal (PDA) Canopy Override Switch AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Triple Vault Cabinet Patron Fare Display LANE LEVEL Receipt Printer COMPONENT Booth Speaker Lane Controller Touch Screen Autosense II Autosense il Traffic Loop Treadle Pad VES Camera Coin Sorter VES Lights Inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for connectivity Inspect and check for functionality Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window inspect and clean Clean Front Lens Inspect / Test Inspect INTERVAL 3 Months 3 Months 3 Months 3 Months 1 Month 1 Month 1 Month 2 Week 1 Week N/A ΝŅ **F**5 \sim 10 7 200 5 2 B N A 50 BC BC BC RCIR BC N/A 0 TRMI INITIALS 2 0 **1**(2) Š P5 707 DC N/A N Riec R 53 RC RC R DC 03 BO 00 Z 10 N A Pi RC 8 ₹5° () N/N 13 N. COMMENTS

1.467 J. 14 J. 12